

HONDA 50 PX

CARBURETTOR KIT Art. 1610693

- Remove the original carburettor kit, replace the gaskets and check if the thermal spacer is in perfect conditions (if it is damaged, replace it with a new one).
- Replace the gas cable from cable splitter to carburettor and adjust the cable so that the complete opening of carburettor and lubricating pump open simultaneously.
- Connect the starter transmission and the fuel tube.
- Drill 6 holes \varnothing 14 in the original air filter cover and insert the 6 supplied small tubes. **(Fig. 1)**
- Insert the two filter elements supplied with the kit into the original metallic filter frame and into the rubber air intake tube. **(Fig. 2)**

